

INSTALLATION SPECIFICATIONS & INFORMATION 2001

Proper Location of Sunroof

Determine the front to back position of the sunroof by placing the template inside the vehicle and determining the best possible position on the headliner. Transfer this position to the outside roof skin by dimpling the roof with an awl poked through the template at least 4 inches within the cut out area. Establish the vehicle center line by measuring side to side on the vehicle and dividing by two. Center the template on this line using the dimple to establish the front to back position. The depth measurements given in this guide are from where the windshield meets the interior trim at the inside center of the vehicle. These specifications are intended to be guidelines only. Car manufacturers may change specifications without notice.

SFC and CRL do not accept responsibility for any sunroof location. Highlighted areas reflect a general recommendation. It is the installer s responsibility to check and verify each application before beginning the installation.

**All Measurements Are Taken From The Interior And Are Shown With
An Accuracy of +/- 1 Inch**

Interior Trim Ring Selection

The selection of the proper trim ring reflects an installer s choice, technique and ability. The T5 & T6 trim rings are universal and can be adapted to a variety of headliner thicknesses. Adapting the ring to the desired configuration is shown on the installation instructions provided with the sunroof. The objective is to create a stack dimension which will firmly squeeze the sealant, steel roof top, shim and headliner together. (Approx. 7/8 Inch) If a trim ring other than the one pre-assembled to your sunroof is used, be sure to pre-assemble this new ring to the frame for easier installation.

NOTE	EXPLANATION OF NOTES
D	It is necessary to move the domelight. In most cases, you may reuse the original mounting bow or a section of it. Make sure that this mounting bow is grounded if it had been used as a ground in its original installation. Always remove the domelight fuse before cutting to prevent an electrical short.
B	A roof bow must be moved, removed or modified in order to properly place the sunroof. The portion of the bow at the edge of the sunroof installation must be trimmed to allow a one inch space between the edge of the sunroof and the cut end of the bow. This allows for proper shimming and a better finished product.
Ds	A double steel roof is indicated by this symbol. Be aware of this factor when cutting the vehicle s roof and when determining the trim ring that you use.
W	A wrapped headliner installation is recommended by this note. This may allow a closer fit to the side rails or the header of the vehicle and will give any vehicle an OEM appearance.
F	A Newport 1828 (non DCS) sunroof is recommended for this application. This version of the NP1828 is not dual contoured and fits better in vehicles with flatter roofs.
Consoles	Many vehicles, especially with higher trim level options, have overhead consoles. Modifications to this console may be required to install sunroofs in these vehicles. SFC Sunroofs does not provide exact specifications for this modification. Each vehicle may require a customized installation.
Δ	This sunroof will fit in the vehicle listed. It will require expert installation and placement to assure a proper fit. Because of the intricacies of this installation, a setback measurement or notes may not be given.

2001 Sunroof Application Guide

Printed in the USA
Unauthorized Reproduction
of this Material is Prohibited

SFC and CRL do not accept responsibility for any sunroof location. Highlighted areas reflect a general recommendation.
Further information is available in our Instructions and Troubleshooting Guide.

2001 MAKE/MODEL	1530 Depth,Notes	1735 Depth,Notes	1432 Depth,Notes	1528 Depth,Notes	1636 Depth,Notes	1732 Depth,Notes	1828 Depth,Notes	ES100 Depth,Notes	ES300 ES500 Depth,Notes	2032 Depth,Notes	2238 Depth,Notes	Comment
ACURA												
Integra	9		9	9		8	11,D,B	9,D,B	9,D,B	9,D,B		
AUDI												
A4,S4	10,B		10,B	10,B		10,B	10,B	12,B	12,B	10,B		
A4 Avant	All Inspected Vehicles Have Factory Installed Sunroofs											
A6	All Inspected Vehicles Have Factory Installed Sunroofs											
A6 Avant	10	10	10	10		10	10,F	12	12	10		
A8	All Inspected Vehicles Have Factory Installed Sunroofs											
TT Coupe							12					
BMW												
All Inspected Vehicles Have Factory Installed Sunroofs												
BUICK												
Century	9,B		9,B	9,B		9,B	12,B	14,B	14,B	12,B		
Le Sabre	14,B	14,B	14,B	14,B	14,B	14,B	14,B	16,B	16,B	14,B		
Park Avenue	13,B		13,B	13,B		13,B	13,B	15,B	15,B	13,B		
Regal	11,B		11,B	11,B		11,B	10,B	13,B	11,D,B	9,D,B		
Rendezvous	9	9	9	9	9	9	9	10	10,D	8,W,D		console
CADILLAC												
Catera			10,B	10,B		10,B	12,B,F	12,B	12,B	10,B		
DeVille						12,B	12,B,F	14,B	14,B	12,B		
Eldorado						12,B	12,B,F	14,B	14,B	12,B		
Escalade	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds		9,Ds	8,Ds	8,Ds		console
Seville						12,B	12,B,F	14,B	14,B	12,B		
CHEVROLET												
Astro Van			Δ	Δ								flatten ribs
Avalanche	14		14	14	14	14	14	14	14	14		console
Blazer	9	9	9	9	9	9	9	10,D	10,D	8,W,D		console
Camaro	No Sunroof Recommended Due to Structural Roof Brace-Do Not Remove!											
Cavalier 2 Dr	9,D					9,D	9,D	11,D	11,D	9,D		
Cavalier 4 Dr				9,D			10,D					wide side rails
Express Van					Δ							flatten ribs
Impala	12,B		12,B	12,B		12,B	12,B,F	14,B	14,B	12,B		
Malibu	14,D,B		15,D,B	8,B		12,D,B	11,D,B	11,D,B	11,D,B	10,D,B		
Monte Carlo	12,B		12,B	12,B		11,B	10,D,B	12,D,B	12,D,B	16,D,B		deep contour in front
Prizm	12,D,B		13,D,B	9,B		11,D,B	10,D,B	10,D,B	10,D,B	10,D,B		
S-10 Pickup Extended Cab	9	9	9	9	9	9	9	11,B	11,B	9,B	9,B,W	
S-10 Pickup Standard Cab	9	9	9	9	9	9	9	11,D	11,D	8,W,D		
Silverado Crew Cab	13B		13B	13B	13							console, ribbed roof
Silverado Extended Cab	12B		12,B	12,B	11,B	11,B		11,B	10,B	10,B		console
Silverado Standard Cab	12B		12,B	12,B	11,B	11,B		11,D,B	10,D,B	10,D,B		console
Suburban	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds		9,Ds	8,Ds	8,Ds		console
Tahoe	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds		9,Ds	8,Ds	8,Ds		console
Trailblazer	9	9	9	9	9	9	9	10	10,D	8,W,D		console
Tracker	7		7	7		7	7,F	9,D,B	9,D,B			ribbed roof
Venture									13,B	11,B		console
CHRYSLER												
300M, LHS	14,B		14,B	14,B		14,B	14,B	15,B	15,B	14,B		
Concorde	14,B		14,B	14,B		14,B	14,B	15,B	15,B	14,B		console
PT Cruiser	12		12	12		12	12	12	12	12		
Sebring 4 Dr	10		10	10		13,D,B	12,D,B	11,D,B	11,D,B	10,D,B		
Sebring Coupe							12,B					4 drop in headliner
Town & Country Van	10,B		10,B	10,B	10,B	10,B	10,B	12,B	12,B	10,B		console
DAEWOO												
Korando	10	10	10	10	10	10	10	12	12	10		
Lanos	8		8	8		13,D,B	12,D,B	10,D,B	10,D,B	10,D,B		
Leganza	12		12	12		12	11,D,B	13,D,B	13,D,B	14,D,B		
Nubira	10,B		10,B	10,B		10,B	10,B	9,B	9,D,B	9,D,B		
Rezzo	12		12	12		12	12	12	12	12		
DODGE												
Caravan	10,B		10,B	10,B	10,B	10,B	10,B	11,B	11,B	10,B		console
Dakota Pickup Ext Cab	10		10	10	10	10		11				console
Dakota Pickup Quad Cab	No roof recommended											
Dakota Pickup Std Cab	10		10	10	10	10		11				ribs, console
Durango	7,D		7,D		7,D,D	7,D						no genesis, console
Full Size Ram Van	12				12				12	12		
Intrepid	14,B		14,B	14,B		14,B	14,B	15,B	15,B	14,B		
Neon	9,D		9,D	9,D		9,D	9,D,B	9,D,B				
Ram Pickup Quad Cab	14.5,D		14.5,D	14.5,D	14.5,D							console
Ram Pickup Standard Cab	14.5,D		14.5,D	14.5,D	14.5,D							

SFC and CRL do not accept responsibility for any sunroof location. Highlighted areas reflect a general recommendation.
Further information is available in our Instructions and Troubleshooting Guide.

D=Move Domelight
Δ=Difficult Installation (Tight Fit)

B=Roof Bow

Ds=Double Steel Roof

W=Wrapped Install Recommended

F=Single Contour 1828 Only

Console=Console Modification Required w/some trim packages

2001	1530	1735	1432	1528	1636	1732	1828	ES100	ES300 ES500	2032	2238	Comment
MAKE/MODEL	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	
DODGE (Continued)												
Stratus Coupe							12,B					4 drop in headliner
Stratus Sedan	10		10	10		13,D,B	12,D,B	11,D,B	11,D,B	10,D,B		
FORD												
Contour	10,B		8,B	8,B		10,B	10,B	12,B	12,B	10,B		
Crown Victoria						13,D,B	12,D,B	14,D,B	14,D,B	12,D,B		
Econoline Van			10,D	10,D	10,D							fill roof ridges
Escape	11		12	12	12	12,B	12,B					
Escort ZX2	7,B		7,B	8,B		11,D,B	10,D,B	10,D,B	10,D,B	8,D,B		
Expedition	11,B		11,B	11,B		13,D,B	12,D,B	13,D,B	13,D,B	11,D,B		ribs, console
Explorer	10		10	10		10	10	10	10	10		ribs, console
Explorer 2002						13						
Explorer Sport Trac	10		10	10		10	10	10	10	10		ribs, console
F-150 Extended Cab	10		10	10	10	10	11	12	12	10		
F-150 Standard Cab	10,B		10,B	10,B	10,B	10,B	10,D,B	11,D,B	11,D,B	10,D,B		
F-150 Supercrew					10	10						ribs, console
F-250 Extended Cab	10,B		10,B	10,B	10,B	10,B	11,B	12,B	12,B	10,B		
F-250 Standard Cab	10,B		10,B	10,B	10,B	10,B	11,B	12,B	12,B	10,B		
Focus	10		10	10		10	10	10	10	10		
Superduty Pickup 250/350	10,B		10,B	10,B	10,B	10,B	11,B	12,B	12,B	10,B		
Mustang	8,B		8,B	8,B			9,D,B	10,D,B	10,D,B	9,D,B		
Ranger Extended Cab	8,B		9,B	9,B	7,B	7,B	11,D,B	9,D,B	9,D,B	9,D,B		
Ranger Standard Cab	9,B		9,B	9,B	8,B	8,B		10,B				
Taurus	9		10	10		12,D,B	10,D,B	12,D,B	11,D,B	10,D,B		
Taurus Wagon	10		10	10		9,D,B		11,D,B				
Windstar Van	10		10	10		10	12,D,B	11,D,B	11,D,B	11,D,B		
GMC												
Denali	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds		9,Ds	8,Ds	8,Ds		console
Envoy	14		14	14	14	14	14	14	14	14		console
Jimmy	9	9	9	9	9	9	9	10	10,D	8,W,D		console
Safari			Δ	Δ								
Savana Van					Δ							flatten ribs
Sierra Crew Cab	13B		13B	13B	13							console, ribbed roof
Sierra Extended Cab	12B		12,B	12,B	11,B	11,B		11,B	10,B	10,B		console
Sierra Standard Cab	12B		12,B	12,B	11,B	11,B		11,D,B	10,D,B	10,D,B		console
Sonoma Pickup Extended	9	9	9	9	9	9	9	10	10,B	9,B	9,B,W	
Sonoma Pickup Standard	9	9	9	9	9	9	9	10	10,D	8,W,D		
Suburban	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds		9,Ds	8,Ds	8,Ds		console
Yukon	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds	10,Ds		9,Ds	8,Ds	8,Ds		console
HONDA												
Accord	14,D,B		15,D,B	10,B		12,D,B	11,D,B	12,D,B	12,D,B	11,D,B		large rear brace (coupe)
Civic 2 Dr, 3 Dr	11,B		11,B	10,B		9,B	11,D,B	11,D,B	11,D,B	11,D,B		
Civic 4 Dr	10,B		10,B	10,B		13,D,B	12,D,B	12,D,B	12,D,B	10,D,B		
CRV	11,B		11,B	11,B		11,B	11,B	12,D,B	12,D,B	11,D,B		
EV	12		12	12		15,D,B	14,D,B	12,D,B	12,D,B	12,D,B		
Odyssey	13,B		13,B	13,B		13,B	13,B	15,B	15,B	13,B		
Passport	11	11	11	11	11	11	11	12	12	10		
Prelude	All Inspected Vehicles Have Factory Installed Sunroofs											
HYUNDAI												
Accent	12,D,B			9				10,D,B				
Elantra	9		9	9		7	13,D,B	11,D,B	11,D,B	11,D,B		
Elantra Wagon	No Sunroof Recommended Due to Multi-level Roof											
Santa Fe								14,B	14,B	14,B		
Sonata	11,B		11,B	11,B		11,B	10,B	12,D,B	12,D,B	12,D,B		
Tiburon	8,B		8,B	8,B		12,D,B	11,D,B	10,D,B	10,D,B	9,D,B		
XG300	All Inspected Vehicles Have Factory Installed Sunroofs											
INFINITI												
G20, I30, Q45	All Inspected Vehicles Have Factory Installed Sunroofs											
QX4	15,B		15,B	15,B		15,B						
ISUZU												
Amigo	10	10	10	10	10	10	10	11	11	10		
Axiom	13		13	13		13		13,D,B	13,D,B	15,D,B		
Hombre Pickup	9	9	9	9	9	9	9	10,D	10,D	8,W,D		
Hombre Space Cab Pickup	9	9	9	9	9	9	9	10,D	10,D	8,W,D		
Oasis	9,D,B		9,D,B	9,D,B		9,D,B	9,D,B	11,D,B	11,D,B	9,D,B		
Rodeo	10	10	10	10	10	10	10	12	12	10		
Trooper	11,B	15,D,B	12,B	12,B		15,D,B	14,D,B	14,D,B	14,D,B	12,D,B	12,D,B	
JEEP												
Cherokee		10	Use									
Grand Cherokee			15			15		15	15	15		flatten ribs in rear
Wrangler	6		6	6		6	6	6	6	6	6	ribs, fiberglass
KIA												
Optima	13		13	13		12	15,D,B	13,D,B	13,D,B	13,D,B		
SFC and CRL do not accept responsibility for any sunroof location. Highlighted areas reflect a general recommendation. Further information is available in our Instructions and Troubleshooting Guide.												

2001	1530	1735	1432	1528	1636	1732	1828	ES100	ES300 ES500	2032	2238	Comment
MAKE/MODEL	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	
KIA (Continued)												
Rio	12,D,B		12,D,B	9		10,D,B	10,D,B	11,D,B	11,D,B	10,D,B		
Sephia	10,B		10,B	10,B		10,B	13,D,B	10,D,B	10,D,B	11,D,B		
Spectra	10,B		10,B	10,B		10,B	13,D,B	10,D,B	10,D,B	11,D,B		
Sportage 2 Dr	10		10	10		10	10,F	10	10	10		
Sportage 4 Dr	15,D,B		9	10		14,D,B	13,D,B	11,D,B	11,D,B	11,D,B		
LAND ROVER												
Discovery	19	19	19	19	19	19	19	21	21	19		
LEXUS												
All Inspected Vehicles Have Factory Installed Sunroofs												
LINCOLN												
Blackwood					10	10						ribs, console
Continental	17,B		17,B	17,B		17,B	17,B	17,B	17,B	14,B		
LS	15,B		15,B	15,B		15,B	15,B	16,B	16,B	15,B		
Navigator						13						ribs, console
Town Car	12		12	12		11	11	12,B	12,B	13,B		
MAZDA												
626	10	9	10	10		10	9	11,D,B	11,D,B	13,D,B		
Millenia	10		10	10		10,B	10,B	12,B	12,B	11,B		
MPV Van		Δ			Δ	Δ						console must be optional fiberglass top
MX-5 Miata	8		8									
Pickup Extended Cab	8,B		9,B	9,B	7,B	7,B	11,D,B	9,D,B	9,D,B	9,D,B		
Pickup Standard Cab	9,B		9,B	9,B	8,B	8,B						
Prot g	13,D,B		9	9		13,D,B	12,D,B	12,D,B	12,D,B	10,D,B		
Tribute						13						
MERCEDES BENZ												
All Inspected Vehicles Have Factory Installed Sunroofs												
MERCURY												
Cougar				12			12	12				
Grand Marquis		13,D,B			14,D,B	13,D,B	12,D,B	12,D,B	12,D,B	10,D,B		
Mountaineer	10		10	10		10	10	10	10	10		ribs, console
Mountaineer 2002						13						
Mystique	10,B		8,B	8,B		10,B	10,B	10,B	10,B	10,B		
Sable	9		10	10		12,D,B	10,D,B	11,D,B	11,D,B	10,D,B		
Sable Wagon	9		10	10		9,D,B						
Villager	11,B	11,B	11,B	11,B	11,B	11,B	11,B	13,B	13,B	11,B		
MITSUBISHI												
Diamante	10,B		10,B	10,B		10,B	10,B	12,B	12,B	10,B		
Eclipse	11		11	11		11	11	13	13	11		
Galant	10		10	10								heavy brace
Mirage 2 Dr	11		11	11		10		11,D,B	11,D,B	12,D,B		
Mirage 4 Dr	10		10	10		9	13,D,B	11,D,B	11,D,B	11,D,B		
Montero Sport	10,B	10,B	10,B	10,B	10,B	10,B	10,B	12,B	12,B	10,B		console
Montero	8.5	8.5	8.5	8.5	8.5	8.5	8.5	10	10	8.5	13,D,B	
NISSAN												
Altima	10,B		10,B	10,B		9,B	14,D,B	11,D,B	11,D,B	12,D,B		
Frontier Pickup Crew Cab	9,B	9,B	9,B	9,B	9,B	9,B	9,B	9,B	9,B	9,B		
Frontier Pickup Extended	9	9	9	9	9	9	9	10	10	9		
Frontier Pickup Standard	9	9	9	9	9	9	9	9	9	7.5		
Maxima	12		13	13		17,D,B	16,D,B	15,D,B	15,D,B	14,D,B		
Pathfinder	15,B		15,B	15,B		15,B						
Quest	11,B	11,B	11,B	11,B	11,B	11,B	11,B	13,B	13,B	11,B		
Sentra	9,B		9,B	9,B		13,D,B	12,D,B	11,D,B	11,D,B	10,D,B		
Xterra	9		9	9	9	9						
OLDSMOBILE												
Alero	12,D,B		13,D,B	12,D,B		12,D,B	12,D,B	12,D,B	12,D,B	12,D,B		
Aurora	13,B		13,B	13,B		13,B	13,B	15,B	15,B	13,B		console
Bravada	9	9	9	9	9	9	9	10,D	10,D	8,W,D		console
Intrique	12,B		12,B	12,B		12,B	12,B	12,B	12,B	12,B		
Silhouette									12,B	11,B		console
PONTIAC												
Aztek	12,B		13,B	13,B	12,B	12,B	12,B	12,B	12,B	12,B		
Bonneville	13,B		13,B	13,B		13,B	13,B	15,B	15,B	13,B		console
Firebird / Trans Am	No Sunroof Recommended Due to Structural Roof Brace-Do Not Remove!											
Grand Am	12,D,B		13,D,B	12,D,B		12,D,B	12,D,B	12,D,B	12,D,B	12,D,B		
Grand Prix	11,B		11,B	11,B		11,B	11,B	13,B	13,B	11,B		console
Montana									12,D	11,D		console
Sunfire 2 Dr	9,D					9,D	9,D	11,D	11,D	9,D		console
Sunfire 4 Dr				9,D			10,D					console,wide side rails
SAAB												
9-3	14		14	14		14	14	16	16			
9-5	14		14	14		14	14	16	16			
SATURN												
LS	10		10	10		9	16,D,B	12,D,B	12,D,B	13,D,B		

SFC and CRL do not accept responsibility for any sunroof location. Highlighted areas reflect a general recommendation. Further information is available in our Instructions and Troubleshooting Guide.

2001	1530	1735	1432	1528	1636	1732	1828	ES100	ES300 ES500	2032	2238	Comment
MAKE/MODEL	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	Depth,Notes	

D=Move Domelight

B=Roof Bow

Ds=Double Steel Roof

W=Wrapped Install Recommended

F=Single Contour 1828 Only

Δ=Difficult Installation (Tight Fit)

Console=Console Modification Required w/some trim packages

SATIURN (Continued)											
SC	12,D		13,D	13,D		10	11,D	13,D	13,D	11,D	
SC 3 Dr				10			10,D				
SL	10		10	10		10	13,D,B	11,D,B	11,D,B	11,D,B	
SW	10		10	10		10	13,D,B	11,D,B	11,D,B	11,D,B	
SUBARU											
Forester							15,D,B				roof rack, heavy brace
Impreza 2 Dr	9,B		9,B	9,B		12,D,B	11,D,B	11,D,B	11,D,B	9,D,B	
Impreza 4 Dr	9		9	9		9	11,D,B	11,D,B	11,D,B	9,D,B	
Impreza Wagon			7	7							roof rack
Legacy	11,B		11,B	12,B		13,D,B	12,D,B	12,D,B	12,D,B	10,D,B	
Legacy Outback Wagon	No Sunroof Recommended Due to Multi-level Roof										
Legacy Wagon	11		11	11							
SUZUKI											
Esteem	9		9	9		9	8	13,D	13,D	13,D	
Esteem Wagon	9,B		9,B	9,B		9,B	9,B	10,B	10,B	8,B	
Grand Vitara	7		7	7		7	7,F	9,D,B	9,D,B		ribbed roof
Grand Vitara XL7	10		10	10		9	13D,B	9,D,B	9,D,B		ribbed roof
Swift	9		9	9	9		9		11	9	
TOYOTA											
4-Runner	8.5		8.5	8.5	8.5	8.5	8.5	10	10	8.5	
Avalon	16,D,B					14,D,B	14,D,B	16,D,B	16,D,B	14,D,B	
Camry	10,B		11,B	11,B		12,D,B	11,D,B	12,D,B	12,D,B	10,D,B	
Celica	10,B		10,B	10,B		10,B	10,B	12,B	12,B	10,B	
Corolla	12,D,B		13,D,B	9,B		11,D,B	10,D,B	11,D,B	11,D,B	10,D,B	
ECHO	9		9								
Highlander	14		14	14	14	14	14	14	14	14	console
Land Cruiser	All Inspected Vehicles Have Factory Installed Sunroofs										
RAV4 4 Dr	13,B		13,B	13,B	12	13,B	13,B	13,B	13,B	13,B	
Sequoia	12		12	12	12	12	12	12	12	12	console
Sienna	17,B	17,B	17,B	17,B		17,B	17,B			17,B	
Solara	10,B		11,B	11,B		10,D,B	12,D,B	12,D,B	12,D,B	10,D,B	
Tacoma 4 Dr	10		10	10		10	10,F	10	10	10	
Tacoma Extended Cab	9	9	9	9	9	9	8	9	9	7	7
Tacoma Standard Cab	9	8	9	9	9	9	8	10			
Tundra	12	12	12	12	12	12	12	11	11	11	
VOLKSWAGEN											
Beetle				16			16				
EuroVan	11		11	11							
Golf & GTI	11,B		11,B	11,B		11,B	11,B,F	12,B	12,B	11,B	
Jetta	11,B		11,B	11,B		11,B	11,B,F	12,B	12,B	11,B	
Passat	12,B		12,B	12,B		12,B	12,B	14,B	14,B	12,B	
Passat Wagon	12		12	12		12,D,B	12,D,B				
VOLVO											
C70,S70,V70	12		12	12		12,B	12,B	12,B	12,B	12,B	
S40,V40	10		10	10		10	10,B	10,B	10,B	10,B	
S60,V60	12		12	12		12,B	12,B	12,B	12,B	12,B	
S80	All Inspected Vehicles Have Factory Installed Sunroofs										